



## Unloading Containers

Make sure container is positioned level, left to right, so cable will not hit corrugated sidewall when being slid to end of container by forklift.

Remove reel chocks and any positioning boards from each reel. Pull nails from floor, or break them off as you go for safety reasons. Nails will puncture boot soles very easily.

Slide sling with knot under reel so the knot is positioned directly behind front flange of reel.

Connect slings as needed for length and loop over forklift brackets.

Slowly and safely, pull with forklift to slide the reel near the end of the container, making sure to slow down and stop short of pulling the reel off the end. Only pull as far as needed so forks can get under each reel.

After container is unloaded, make sure all nails are pulled or broken off flush with floor and sweep container out. There is a cleaning charge if not left ready for next shipment.

Thanks for your business!

**Western Supply**

1601 E Peoria #222  
Paola KS 66071

913-706-6659

## Tools & Equipment Needed.

Fork Lift, 3 ft wrecking bar, 3 lb hammer, claw hammer, 5-20 ft slings (or 3 for 20' Container), push broom, step ladder.



Make sure container is positioned level, left to right, so cable will not hit corrugated sidewall when being slid to end of container by forklift.







Remove reel chocks and any positioning boards from each reel. Pull nails from floor, or break them off as you go for safety reasons. Nails will puncture boot soles very easily.



Tie a double knot in the center of one of the slings to act as a catch under the reel flange.

Chains or cables are not safe, only use fabric slings



Slide sling with knot under reel so the knot is positioned directly behind front flange of reel





Connect slings as needed for length and loop over forklift brackets.







Slowly and safely, pull with forklift to slide the reel near the end of the container, making sure to slow down and stop short of pulling the reel off the end. Only pull as far as needed so forks can get under each reel.





After container is unloaded, make sure all nails are pulled or broken off flush with floor and sweep container out. There is a cleaning charge if not left ready for next shipment.

